


EVO Setup



HDMI Connection →

HDMI allows you to take full advantage of the Evolution Digital HD Set-Top Box high-definition digital features.

1. Connect the coaxial cable to the cable wall outlet and the "CABLE IN" port on the cable box.
2. Connect the HDMI cable to the "HDMI" port on HD Set-Top Box and the "HDMI" port on your HDTV.
3. Connect the power cord to the electrical wall outlet and the "DC 5V IN" port on the HD Set-Top Box.

Note: HDMI cables carry audio and video to the TV.

SD Coaxial Audio/Video Connection ←

1. Connect the RF coaxial cable to the cable wall outlet and the "CABLE IN" port on the HD Set-Top Box.
2. Connect the smaller RF coaxial cable to the "RF OUT" port on the HD Set-Top Box. Connect the other end to the input port on the TV.
3. Connect the power cord to the electrical wall outlet and the "DC 5V IN" port on the HD Set-Top Box.

Note: Make sure the channel 3/4 switch matches the channel on your TV. For example, if your cable box is set to "3", make sure your TV is on channel "3".

Programing Remote to TV

1. Turn on your TV
2. On your remote, press and hold the **SETUP** button until the **INDICATOR LED** changes from red to green.
3. Press the **YELLOW A** button.
4. Press the **CH▲** button multiple times until the **TV** Turns off.
5. After **TV** turns off, press **SETUP**.
6. 2 Green Blinks means it worked.